

CARE AND MAINTENANCE









Store outdoor furniture indoors or cover well when not in use.
Remove wooden furniture from standing water. Dust regularly with small brush or vacuum
Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening



Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat frame		1X
B	Back frame		1X
C	Leg frame-1		1X
D	Leg frame-2		1X
E	Screw -1	 M6x80	2X
F	Screw -2	 M6x60	4X
G	Bolt	 M8x50	2X
H	Allen key	 4 mm	1X

Model# PAT7041
Product Dimensions:24.4" W x 24.8" D x 33.85" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 30 minutes.

Tools Required for Assembly (included): Allen Key


1




3



2



4



Step 1

Attached seat frame (A) to back frame (B).

Step 2

Using screw (F), tighten by (H).

Step 3

Attached leg frame (C), (D) to back frame (B) and seat frame (A).

Step 4

Using screw (E) to front leg and Using Bolt (G) to back frame, tighten by (H).

CARE AND MAINTENANCE











Store outdoor furniture indoors or cover well when not in use.
Remove wooden furniture from standing water. Dust regularly with small brush or vacuum
Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening



Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Top table		1X
B	Long leg		2X
C	Short leg		2X
D	Connection leg		1X
E	Tie legs -1		2X
F	Tie legs -2		1X
G	Screw	 M7x70	6X
H	Bolt	 M8x35 M8x15	8X
K	Whether lid		1X
L	Allen key	 4 mm	

Model# PAT7041
Product Dimensions:35.4" W x 35.4" D x 29.5" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.

Tools Required for Assembly (included): Allen Key


1



Step 1

Attach short leg (C), long leg (B) to (E), (F) by using bolt (H) and screw (G), tighten with allen (L)

2



Step 2

Attach connection leg (D) to short leg (C), by using bolt (H), tighten with allen (L)
Attach short leg (C), long leg (B) to top table (A) by using bolt (H), tighten with allen (L)

3



Step 3

(K) Pull down as the arrow