

CARE AND MAINTENANCE

Do not expose your furniture to any liquids. All liquids should be wiped up immediately with a soft, slightly damp cloth in the direction of the rattan. Do not expose your furniture to strong or direct sunlight, heat outlets, open windows and dampness. Excessive exposure to sunlight can cause fading of your furniture finish. Extreme temperatures and humidity changes can cause cracking and splitting.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
1	Chair Back		1X
2	Chair Seat		1X
3	Chair Bottom		1X
4	Table		1X
5	Chair Pillows		1X
A	Allen bolt(M6x40 mm)		2X
B	Flat washer		2X
C	Allen key		1X



Model# PAT2507
Product Dimensions:
26"x36"x35" H (Chair)
26"x19.7"x17" H (Ottoman)
Φ24.4"x22" H (Table)



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 45 minutes.
Tools Required for Assembly (included): Allen Key


1

Diagram 1 shows the front rail (1) being attached to the seat base (2). The rail is positioned horizontally, and the base is positioned vertically. The rail is secured to the base using two screws, labeled A and B. The rail is shown in a curved position, indicating it is being bent to fit the base.

2

Diagram 2 shows the backrest (1) being attached to the seat base (2). The backrest is positioned horizontally, and the base is positioned vertically. The backrest is secured to the base using two screws, labeled A and B. The backrest is shown in a curved position, indicating it is being bent to fit the base.

3



4

